RADIO INFLUENCE VOLTAGE
vs.
APPLIED VOLTAGE

TYPE VI-A
VEE STRING JUMPER ASSEMBLY

Corona Voltage - 439 KV

June 18, 1965.

RADIO INFLUENCE VOLTAGE (Microvolts)

1000
900
800
700
600
500
400
300
200
100
0

100 150 200 250 300 350 400 450

APPLIED VOLTAGE (Kv - RMS)

FIG. 17

10 X 10 TO THE ½ INCH
KEUFFEL & ESSER CO.
359-11
MADE IN U.S.A.

RADIO INFLUENCE VOLTAGE
vs.
APPLIED VOLTAGE

TYPE VA
DEAD-END STRAIN ASSEMBLY
(INVERTED INSULATOR ARRANGEMENT)

Corona Voltage - 414 KV

June 3, 1965.

RADIO INFLUENCE VOLTAGE (microvolts)

1000
900
800
700
600
500
400
300
200
100
0

100 150 200 250 300 350 400 450

APPLIED VOLTAGE (KV _ RMS)

FIG. 15

10 X 10 TO THE ½ INCH
KEUFFEL & ESSER CO.
359-11
MADE IN U.S.A.